


PCAN-Router

Universal Programmable
CAN Converter

User Manual



Document version 1.5.0 (2019-03-12)

PEAK
System

Relevant products

Product Name	Model	Part number
PCAN-Router	2 D-Sub connectors, additional digital input	IPEH-002210
PCAN-Router	Screw terminal block, additional serial interface	IPEH-002210-P
PCAN-Router opto- decoupled	2 D-Sub connectors, galvanic isolation for connector CAN2, additional digital input	IPEH-002211

PCAN® is a registered trademark of PEAK-System Technik GmbH. CANopen® and CiA® are registered community trade marks of CAN in Automation e.V.

All other product names mentioned in this document may be the trademarks or registered trademarks of their respective companies. They are not explicitly marked by "™" and "®".

© 2019 PEAK-System Technik GmbH

Duplication (copying, printing, or other forms) and the electronic distribution of this document is only allowed with explicit permission of PEAK-System Technik GmbH. PEAK-System Technik GmbH reserves the right to change technical data without prior announcement. The general business conditions and the regulations of the license agreement apply. All rights are reserved.

PEAK-System Technik GmbH
Otto-Roehm-Strasse 69
64293 Darmstadt
Germany

Phone: +49 (0)6151 8173-20
Fax: +49 (0)6151 8173-29

www.peak-system.com
info@peak-system.com

Document version 1.5.0 (2019-03-12)

Contents

1	Introduction	5
1.1	Properties at a Glance	5
1.2	Scope of Supply	6
1.3	Prerequisites for Operation	7
2	Connectors and Coding Solder Jumpers	8
2.1	D-Sub Connectors	9
2.1.1	Supplying External Devices via the CAN Connector (D-Sub only)	11
2.2	Screw Terminal Block	12
2.3	J4 Connector Panel: Serial Ports	13
2.4	J5 Connector Panel: JTAG Ports	14
2.5	Coding Solder Jumpers	15
3	Operation	17
4	Software	18
4.1	Installing the GNU ARM Toolchain	18
4.2	Library	19
4.3	Firmware Examples	19
4.3.1	Compiling a Firmware Example	20
5	Firmware Upload	21
5.1	Uploading Firmware via CAN	21
5.1.1	System Requirements	21
5.1.2	Preparing Hardware and Software	22
5.1.3	Uploading the Firmware	23
5.2	Uploading Firmware via the Serial Connections	26
6	Technical Specifications	28

Appendix A	CE Certificate	30
Appendix B	Dimension Drawings	31
Appendix C	Port Assignment of the Microcontroller	32

1 Introduction

The PCAN-Router is a dual-channel CAN module whose NXP LPC21 series programmable microcontroller provides the option of using the CAN messages on both channels on a flexible basis. This gives a whole range of options for manipulation, evaluation, filtering, and routing of CAN messages.

Using the supplied library and the Yagarto GNU ARM toolchain (contains the GNU Compiler Collection GCC for C and C++), custom firmware can be created and then transferred to the module via CAN. At delivery, the PCAN- Router is equipped with a demo firmware that forwards CAN messages 1:1 between both channels at 500 kbit/s. The corresponding source code is included as example in the scope of supply.

The module is installed in an aluminum profile casing, and is shipped in versions with two D-Sub connectors or a screw terminal block.

1.1 Properties at a Glance

- └ NXP LPC21 series microcontroller (16/32-bit ARM CPU)
- └ 32 kByte EEPROM
- └ Two High-speed CAN channels (ISO 11898-2) with bit rates from 40 kbit/s up to 1 Mbit/s
- └ Complies with CAN specifications 2.0 A/B
- └ Galvanic isolation of the D-Sub connector CAN 2 (only applies to the opto-decoupled model)
- └ Status signaling with two 2-color LEDs

- └ Connection via two 9-pin D-Sub connectors or one 10-pole screw terminal block (Phoenix)
- └ Additional digital input (only applies to models with D-Sub connectors)
- └ Aluminum casing, optionally available with DIN rail mounting on request
- └ Supply voltage from 8 to 30 V
- └ Extended operating temperature range of -40 to 85 °C (-40 to 185 °F)
- └ Import of a new firmware via CAN
- └ Additional serial RS-232 interface (only applies to model with screw terminal block)

1.2 scope of supply

- └ PCAN-Router in aluminum casing
- └ IPEH-002210-P: mating connector (Phoenix)¹
- └ Windows development software (Yagarto GNU ARM toolchain, flash program)
- └ Library with programming examples
- └ Manual in PDF format

¹ Phoenix Contact MC 1,5/10-ST-3,81 - 1803659

1.3 Prerequisites for Operation

- └ Voltage supply within a range of 8 to 26 V DC (up to 30 V with IPEH-002210(-P) from ser. no. 01000 and IPEH-002211 from ser. no. 00020)
- └ For uploading a new firmware via CAN:
 - CAN interface of the PCAN series for the computer (e.g. PCAN-USB)
 - Operating system Windows 10, 8.1, and 7 (32/64-bit)

2 Connectors and Coding Solder Jumpers

Depending on the model the PCAN-Router has the following connectors:

- └ two 9-pin D-Sub connectors (IPEH-002210/11)
- └ one 10-pin screw terminal block (IPEH-002210-P)

For direct access to the serial and debugging ports of the micro-controller, additional – yet not equipped – connector panels are available on the board of the PCAN-Router.

Furthermore the PCB has four coding solder jumpers in order to assign a fixed status to the corresponding input bits of the micro-controller. A concrete application is to identify a PCAN-Router on the CAN bus for a firmware upload, especially if there are several routers connected and in operation.

The following subsections describe each connector assignment.

2.1 D-Sub Connectors


(IPEH-002210 and IPEH-002211)

The two D-Sub connectors are used for the CAN channels CAN1 and CAN2.

The voltage supply can be done via both connectors, with the opto-decoupled model only via connector CAN1. The supply connections $+U_{b1}$ and $+U_{b2}$ are connected internally in a reactionless configuration. This means that different power sources can be connected if applicable.

Connector CAN1 additionally offers an input to activate the bootloader named Boot CAN1 (see also section 5.1 *Uploading Firmware via CAN* on page 21).

Connectors CAN2 or CAN1 (see assignment tables below) have an additional digital input named Din0 which can be utilized by the microcontroller.



Pin distribution D-Sub connector

PCAN-Router IPEH-002210:

Pin	Function connector CAN1	Function connector CAN2
1	+5 V for external devices (optional) ²	+5 V for external devices (optional) ²
2	CAN1_L	CAN2_L
3	GND	GND
4	Reserved	Not used
5	SHIELD	SHIELD
6	Boot CAN1 (High-active)	Not used
7	CAN1_H	CAN2_H
8	Not used	Din0 (Low-active)
9	Supply +U _{b1} ³	Supply +U _{b2} ³

PCAN-Router opto-decoupled IPEH-002211:

Pin	Function connector CAN1	Function connector CAN2
1	+5 V for external devices (optional) ²	+5 V for external devices (optional, via DC/DC converter) ²
2	CAN1_L	CAN2_L
3	GND1	GND2
4	Reserved	Not used
5	SHIELD	SHIELD
6	Boot CAN1 (High-active)	Not used
7	CAN1_H	CAN2_H
8	Din0 (Low-active)	Not used
9	Supply +U _{b1} ⁴	Not used

² See following subsection 2.1.1³ 8 - 26 V DC, up to 30 V from ser. no. 01000⁴ 8 - 26 V DC, up to 30 V from ser. no. 00020

2.1.1 Supplying External Devices via the CAN Connector (D-Sub only)


On the circuit board of the PCAN-Router a 5-Volt supply can optionally be routed to each pin 1 of the D-Sub connectors CAN1 and CAN2. Thus devices with low power consumption (e.g. bus converters) can be directly supplied via the CAN connector. The current consumption may not exceed **100 mA** per connector.

➡ Proceed as follows to activate the 5-Volt supply:


In order to remove the circuit board unscrew the casing of the PCAN-Router on both ends and pull the board from the casing profile.

Set the solder jumper(s) on the circuit board according to the desired settings. During this procedure take especially care not to produce unwanted short circuits on the board.





The following figures show the positions of the solder fields on the bottom side of the PCAN-Router circuit board. The table below contains the possible settings.



IPEH-002210 up to ser. no. 00458




IPEH-002210 from ser. no. 00459
and all IPEH-002211

5-Volt supply →	None	Pin 1
CAN1 (R35)		
CAN2 (R36)		

2.2 Screw Terminal Block

(IPEH-002210-P)

Apart from power supply and CAN channels, the screw terminal block includes connections for a serial interface with RS-232 levels.




Terminal	Function
1	Supply +U _b ⁵
2	GND
3	CAN1_L
4	CAN1_H
5	CAN2_L
6	CAN2_H
7	Boot CAN1 (High-active)
8	Reserved
9	RS-232 RxD
10	RS-232 TxD

For further connection details that are not needed for programming of the PCAN-Router because of implementation in a library, see also Appendix C *Port Assignment of the Microcontroller* on page 32.


⁵ 8 - 26 V DC, up to 30 V from ser. no. 01000

2.3 J4 Connector Panel: Serial Ports

The unpopulated connector panel J4 on the board of the PCAN-Router provides an access option to the serial ports of the LPC2129 or LPC2194/01 microcontroller (μC).



IPEH-002210(-P) up to ser. no. 00458



IPEH-002210(-P) from ser. no. 00459
and all IPEH-002211

Pin	Signal	Port μC
1	RxD0	P0.1
2	TxD0	P0.0
3	Not used	
4	/Boot_ser	P0.14
5	GND	
6	+5.0 V	


The RxD0 and TxD0 signals are forwarded to a level converter for the RS-232 standard. The PCAN-Router model with screw terminal block provides access to the adjusted signals at terminals 9 (RS-232 RxD) and 10 (RS-232 TxD).




Attention! The RxD0 (pin 1) and TxD0 (pin 2) signals in connector panel J4 are designed for TTL levels only. Using RS-232 levels at these connections can cause damage to the electronics of the PCAN-Router.

2.4 J5 Connector Panel: JTAG Ports

The unpopulated connector panel J5 on the circuit board of the PCAN-Router provides an access option to the JTAG ports of the LPC2129 or LPC2194/01 microcontroller (μC) for hardware debugging.



IPEH-002210(-P) up to ser. no. 00458




IPEH-002210(-P) from ser. no. 00459
and all IPEH-002211

Pin	Signal	Port μC	Internal wiring
1, 2	GND		
3	/Reset	/Reset	Pull-up
4	3.3 V		
5	TCK	P1.29	Pull-down (R30)
6	TMS	P1.30	Pull-up
7	TDO	P1.27	Pull-up
8	TDI	P1.28	Pull-up
9	RTCK	P1.26	Pull-down (R31)
10	TRST	P1.31	Pull-up


If constant internal pull-down wiring of the TCK or RTCK signals is not suitable for your purposes, you can remove the respective pull-down resistor on the circuit board of the PCAN-Router by soldering it out. Both resistors (each 10 k Ω) are located next to the J5 connector panel J5 (see figures).



IPEH-002210(-P)
up to ser. no. 00458




IPEH-002210(-P) from ser. no. 00459 and all IPEH-002211
Top side of the PCB | Bottom side of the PCB




2.5 Coding Solder Jumpers

The four positions for coding solder jumpers (ID 0 - 3) are each assigned to one port of the microcontroller LPC 2129 or LPC2194/01 (µC).



IPEH-002210(-P) up to ser. no. 00458



IPEH-002210(-P) from ser. no. 00459
and all IPEH-002211

Position	0	1	2	3
Port µC	P0.4	P0.5	P0.6	P0.7

Position is ...	Status at the port
bridged	Low
open	High

The status of the ports is relevant in the following cases:

- The loaded firmware is programmed so that it reads the status at the corresponding ports of the microcontroller. For example, the activation of certain functions of the firmware or the coding of an ID is conceivable here.

- For a firmware upload via CAN the PCAN-Router is identified by a 4-bit ID which is determined by solder jumpers. A bit is set (1) when the corresponding solder jumper position is open (default setting: ID 15, all positions open).

Position	0	1	2	3
Binary digit	0001	0010	0100	1000
Decimal equivalent	1	2	4	8

See also section 5.1 *Uploading Firmware via CAN* on page 21.

3 operation

The PCAN-Router is activated by applying the supply voltage to the respective input pins (see chapter 2 *Connectors and Coding Solder Jumpers* on page 8). The firmware in the flash memory is subsequently run.

The PCAN-Router is supplied with an example firmware which forwards CAN messages 1:1 between the two channels at 500 kbit/s. An incoming CAN message causes a change between green and orange of the LED status indication for the respective CAN channel.

The source code for the example firmware 1_ROUTING and further examples is included on the supplied DVD in the following directory branch:

```
/Develop/Microcontroller hardware/PCAN-Router/Example/
```

4 Software

This chapter covers the installation of the Yagarto GNU ARM tool-chain and gives notes about the software library and the firmware examples.

Software, source code, and additional information are included on the supplied DVD in the following directory branch:

```
/Develop/Microcontroller hardware/PCAN-Router/
```

4.1 Installing the GNU ARM Toolchain

To compile the code examples and the custom firmware code under Windows, install Yagarto on your computer. Yagarto is a collection of tools to develop applications for ARM processors and microcontrollers on Windows platforms. The collection includes the GNU GCC compiler for C and C++, Make, and further tools. Further information about Yagarto: www.yagarto.de

System requirement: Windows 10, 8.1, and 7 (32/64-bit)

▶ Do the following to install Yagarto:

1. From the directory branch on the provided DVD mentioned above, change to the `Compiler` subdirectory.

The directory contains the two installation programs `yagarto-*.exe` and `yagarto-tools-*.exe`.

2. Execute the first installation program and follow its instructions.

If you don't want to use the default destination folder, make sure that your customized path doesn't contain any spaces. Otherwise compile operations will not work later.

3. Afterwards, execute the second installation program and follow its instructions.

In the system environment, the installation programs create search paths for the executable files. These new search paths are effective only for programs and command prompts that are started afterwards.

4.2 Library

The development of applications for the PCAN-Router is supported by the library `libPCAN-RouterGNU*ys.a` (* stands for version number), a binary file. You can access all resources of the PCAN-Router by means of this library. The library is documented in the header files (`*.h`). The files are located in each example directory.

From version 2 of the library, all models of the PCAN-Router are supported. Software code that is based on a previous version of the library can be used with version 2 without any changes.


4.3 Firmware Examples

On the DVD, the `Example` subdirectory contains source code for several firmware examples that you can use and test directly and that you can reuse for custom firmware.

On delivery the PCAN-Router is supplied with the example firmware `1_ROUTING`. It forwards CAN messages 1:1 between the two CAN channels at 500 kbit/s. An incoming CAN message causes a change between green and orange of the LED status indication for the respective CAN channel.

4.3.1 Compiling a Firmware Example

▶ Do the following to compile a firmware example under Windows:

1. From the provided DVD, copy the subdirectory of the desired example from the `Example` directory to the local hard disk.
2. Open a **command prompt** by using the Windows Start menu. Alternatively you can press the key combination  + **R** and enter `cmd.exe` as program to be executed.
3. At the command prompt change to the previously copied directory.
4. Execute the following command in order to clean-up the target directories (e.g. `.out`) from files that have been generated earlier:

```
make clean
```

5. Execute the following command to compile the firmware example:

```
make all
```

If the compiler has finished without errors ("Errors: none"), you can find the firmware file with the extension `.bin` in the subdirectory `.out`. This file is then used for firmware upload to the PCAN-Router.

5 Firmware Upload

The microcontroller in the PCAN-Router can be equipped with new firmware in two different ways:

- └ Via CAN. The scope of supply includes the Windows program PCAN-Flash to transfer the firmware from the computer to the PCAN-Router. This is the recommended method for a firmware upload.
- └ Via the RS-232 interface or the serial connections of the microcontroller. For the latter access to the board of the PCAN-Router is needed.

5.1 Uploading Firmware via CAN

5.1.1 System Requirements


The following prerequisites must be given, so that the PCAN-Router can be updated with new firmware:

- └ CAN interface of the PCAN series for the computer (e.g. PCAN-USB)
- └ CAN cabling between the CAN interface and the PCAN-Router with proper termination ($120\ \Omega$ on each end of the CAN bus)
- └ Operating system Windows 10, 8.1, and 7 (32/64-bit)
- └ If you want to update several PCAN-Router connected to the same CAN bus, you must assign a unique ID to each router. See section 2.5 *Coding Solder Jumpers* on page 15.


5.1.2 Preparing Hardware and Software

▶ Perform the following steps for preparation of the hardware:

1. Switch the PCAN-Router off by disconnecting it from the power supply.
2. Establish a connection between “Boot CAN1” and “+U_{b1}” or “+U_b” at the connectors of the PCAN-Router.



Connection at D-Sub connector CAN1
between the pins 6 and 9



Connection at the screw terminal
block
between terminals 1 and 7

This measure later applies the “Boot CAN1” connection with a high level.

3. Connect CAN bus 1 of the PCAN-Router with a CAN interface connected to the computer. Pay attention to the proper termination of the CAN cabling (2 x 120 Ω).

Uploading firmware via CAN bus 2 is not possible.



Attention! Risk of short circuit! A CAN cable with D-Sub connectors must not have a connection on pin 6, as it can be seen on 1:1 cables, for example. At other CAN nodes (e.g. a CAN interface of the PCAN series) this line may be applied to the mass. Damage or destruction of the electronics is a possible consequence.

▶ Perform the following steps for preparation of the software:

1. On the supplied DVD, change to the following directory:
/Develop/Microcontroller hardware/PCAN-Router/
2. Copy the subdirectory PcanFlash to the local hard disk.


The contained Windows software that copies the Firmware via CAN (`PcanFlash.exe`) can only be started from a data carrier that is writable.


5.1.3 Uploading the Firmware

▶ The process of uploading new firmware to the PCAN-Router is as follows:


1. Ensure that a connection is established between the "Boot CAN1" and "+U_{b1}" or "+U_b" connections of the PCAN-Router (details: see above).
2. Switch the PCAN-Router on by applying voltage supply.

Due to the High level at the "Boot CAN" connection, the PCAN-Router starts the CAN bootloader. This can be identified by two orange LEDs. Starting with version 2 of the CAN bootloader (standard on IPEH-002210(-P) from ser. no. 00300 and all IPEH-002211) the LED "CAN1" blinks.

3. Run the program `PcanFlash.exe` under Windows from the local hard drive.
4. Click on the  (Options) button in order to call up the dialog box.
5. From the **Hardware Profile** dropdown list, select the **PCAN-Router** entry.




6. Click on the ... button next to the **File name** field in order to select the desired firmware file (*.bin) to be uploaded.
7. Click on the **OK** button.
8. Make sure that the PCAN-Flash program is connected with 500 kbit/s to the available CAN interface at the computer.




PCAN-Flash: Display of a connection in the status bar on the bottom.

If not, click the ⚡ (Connect) button in order to change the selection in the according dialog box.



- Click the 🔍 (Detect) button in order to detect the PCAN-Router connected to the CAN bus.

An entry for the PCAN-Router appears in the main window.



- Select the entry for the PCAN-Router.
- Click the ▶ (Program) button in order to start uploading the new firmware to the PCAN-Router.

Observe the status indication at the bottom of the window. The process was successful if the last message to appear is "Flashing of module(s) finished!".

12. Disconnect the power supply from the PCAN-Router.
13. Disconnect "Boot CAN1" from "+U_{b1}" or "+U_b".

You can now use the PCAN-Router with the new firmware.


5.2 Uploading Firmware via the Serial Connections

This section shows how to activate the microcontroller's boot-loader. The actual upload process depends on the upload software used which is supplied by a third party and is not described here.


Important note: When uploading a firmware via the RS-232 interface, the CAN bootloader may be overwritten. Afterwards a firmware upload via CAN is not possible anymore.

Do the following to activate the microcontroller's bootloader:

1. Switch the PCAN-Router off by disconnecting it from the power supply.
2. Open the casing of the PCAN-Router by removing the screws in order to gain access to the board.
3. Establish a connection on the J4 connector panel between pin 4 (\Boot_ser) and pin 5 (GND).



IPEH-2210(-P) up to ser. no. 00458



IPEH-2210(-P) from ser. no. 00459
and all IPEH-2211

4. Establish a serial connection to the computer or program adapter. This is carried out either via the RS-232 interface (IPEH-002210-P only) or via the serial ports of the microcontroller (TTL levels). See also chapter 2 *Connectors and Coding Solder Jumpers* on page 8.
5. Switch the PCAN-Router on by applying voltage supply.

Due to the Low level on port P0.14 of the microcontroller, the PCAN-Router starts the bootloader for serial copying. Neither LED is illuminated.

6 Technical specifications

Functionality	
Microcontroller	NXP LPC2194/01 with a clock speed of 60 MHz (IPEH-2210(-P) up to ser. no. 00299: NXP LPC2129) Firmware upload via CAN with special bootloader or serial
Add-on memory	256 kbit, EEPROM Atmel AT24C256B (via I ² C) (IPEH-2210(-P) up to ser. no. 00299: 2 kbit, Microchip 24LC02B)
CAN	2 x High-speed CAN ISO 11898-2 Transceiver NXP TJA1040T Bit rates 40 kbit/s - 1 Mbit/s (lower bit rates on request) No termination
RS-232	RxD and TxD serial connections with RS-232 levels (IPEH-002210-P only)
Digital input (Din0)	Low-active, max. level +U _b (IPEH-002210/11 only)
Status indication	2 duo LEDs
Connectors	IPEH-002210: 2 x D-Sub connector, 9-pin, assignment according to specification CiA® 303-1 IPEH-002210-P: 1 x screw terminal block, 10-pin, pitch 3.81 mm (Phoenix Contact MC 1,5/10-ST-3,81 - 1803659) IPEH-002211: like IPEH-002210, galvanic isolation for connector CAN2 up to 500 V
Power supply	
Voltage supply (+U _b)	8 - 26 V DC up to 30 V with IPEH-002210(-P) from ser. no. 01000 and IPEH-002211 from ser. no. 00020
Current consumption	max. 70 mA at 12 V

Measures

Size	Casing: 70 x 55 x 24 mm (L x W x H) Circuit board: 65 x 51 mm (L x W) See also dimension drawings in Appendix A on page 30
Weight	IPEH-002210: 100 g IPEH-002210-P: 100 g (incl. screw terminal block) IPEH-002211: 100 g

Environment

Operating temperature	-40 - +85 °C (-40 - +185 °F)
Temperature for storage and transport	-40 - +100 °C (-40 - +212 °F)
Relative humidity	15 - 90 %, not condensing
Ingress protection (IEC 60529)	IP20

Conformity

EMV	Directive 2014/30/EU DIN EN 61326-1:2013-07
RoHS 2	Directive 2011/65/EU DIN EN 50581 VDE 0042-12:2013-02

Appendix A CE Certificate

EU Declaration of Conformity



This declaration applies to the following product:

Product name: PCAN-Router
Item number(s): IPEH-002210(-P) and IPEH-002211
Manufacturer: PEAK-System Technik GmbH
Otto-Roehm-Strasse 69
64293 Darmstadt
Germany

CE We declare under our sole responsibility that the mentioned product is in conformity with the following directives and the affiliated harmonized standards:

EU Directive 2011/65/EU (RoHS 2)

DIN EN 50581 VDE 0042-12:2013-02

Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances;
German version EN 50581:2012

EU Directive 2014/30/EU (Electromagnetic Compatibility)

DIN EN 61326-1:2013-07


Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 1:
General requirements (IEC 61326-1:2012);
German version EN 61326-1:2013

Darmstadt, 22 February 2019

A handwritten signature in black ink, appearing to read "Uwe Wilhelm".

Uwe Wilhelm, Managing Director

Appendix B Dimension Drawings



The figures do not show the original size.

Appendix C Port Assignment of the Microcontroller

The following table lists the used inputs and outputs (ports) of the LPC2129 and LPC2194/01 microcontroller (µC) and their function in the PCAN-Router. It is meant as supplemental information. The converter's functionality is implemented by the supplied library.

Get additional information about the LPC2129 and LPC2194/01 microcontrollers on the homepage of NXP (www.nxp.com).

Port	I/O	µC function	Signal	Active (µC)	Function/connection ⁶
P0.0	O	TxD UART0	TxD0		Serial communication, Transmit, J4:2 or STB:10 (RS-232 levels)
P0.1	I	RxD UART0	RxD0		Serial communication, Receive, J4:1 or STB:9 (RS-232 levels)
P0.2	I, O	SCL	SCL		I ² C bus to the EEPROM Microchip 24LC02B or Atmel AT24C256B ⁷
P0.3	I, O	SDA	SDA		
P0.4	I	Port pin	ID0	High	Coding solder jumpers on board (ID 0 - 3), bridged = Low
P0.5	I	Port pin	ID1	High	
P0.6	I	Port pin	ID2	High	
P0.7	I	Port pin	ID3	High	
P0.8	O	TxD UART1			
P0.9	I	RxD UART1			
P0.10	O	Port pin			

⁶ CAN1/2:n Pin n of the respective D-Sub connector

STB:n Terminal n on the screw terminal block

J4/5:n Pin n of the respective connector panel on the board

⁷ PCAN-Router IPEH-002210(-P) from serial number 00300 and all IPEH-002211

Port	I/O	µC function	Signal	Active (µC)	Function/connection ⁶
P0.11	I	Hardware capture with timer			
P0.12	O	Port pin			Reserved
P0.13	I, O	Port pin			
P0.14	I	Port pin	/Boot_ser	Low	Activate flashing via serial interface, J4:4
P0.15	I	Port pin	/Boot_CAN	Low	Activate flashing via CAN1 with 500 kbit/s, CAN1:9 and STB:7 (due to wiring High-active)
P0.17	O	Port pin	V24_en	High	Deactivate the RS-232 converter by Low level (activated by default); possibility for energy saving
P0.18	I	Hardware capture with timer			
P0.19	I	Port pin	Switch	High	Digital input Din0, CAN2:8 (due to wiring Low-active)
P0.20		Hardware capture with timer			
P0.21	O	Port pin	CAN_en_2	Low	Activate the respective CAN transceiver ⁸
P0.22	O	Port pin	CAN_en_1	Low	
P0.23	I	RD2	CAN2_RxD		CAN2 Receive
P0.24	O	TD2	CAN2_TxD		CAN2 Transmit
P0.25	I	RD1	CAN1_RxD		CAN1 Receive
TD1	O	TD1	CAN1_TxD		CAN1 Transmit

⁸ After resetting the microcontroller, the CAN transceivers are deactivated and must be reactivated to use them.

Port	I/O	µC function	Signal	Active (µC)	Function/connection ⁶
P0.27	I	Analog input	V-Power2		Measure voltage +U _{b2} , maximum value (0x03FF) corresponds to approx. 16.5 V
P0.28	I	Analog input	V-Power1		Measure voltage +U _{b1} or +U _b , maximum value (0x03FF) corresponds to 33.1 V
P0.29	I	Analog input			Lies on GND
P0.30	I	Analog input			Lies on 1.8 V (microcontroller supply)
P1.16	O ⁹	Port pin		Low	LED CAN1 red
P1.17	O ⁹	Port pin		Low	LED CAN1 green
P1.18	O ⁹	Port pin		Low	LED CAN2 red
P1.19	O ⁹	Port pin		Low	LED CAN2 green
P1.25	O				
P1.26		JTAG interface	RTCK		Debugging, J5:9
P1.27		JTAG interface	TDO		Debugging, J5:7
P1.28		JTAG interface	TDI		Debugging, J5:8
P1.29		JTAG interface	TCK		Debugging, J5:5
P1.30		JTAG interface	TMS		Debugging, J5:6
P1.31		JTAG interface	TRST		Debugging, J5:10

⁹ It may occur that an LED glows slightly when the respective output is inactive. If you would like to prevent this, your firmware must change the port type to input (I). Before switching on the LED again, the respective port type must be set to output (O).